



Product Description

Colonnade downpipes are available in circular, square, rectangular and security styles. With a number of different profiles, they are lightweight and easy to fit. Ideal for any property, from modern to traditional and equally suited for refurbishment of Heritage or Listed properties.

Properties

Made from aluminium extrusion 6060 T4 to BS1474:1972
 100% recyclable
 Lightweight and low maintenance
 Special fittings can be provided
 Available Mill Finished (uncoated) or coated on ARP's in-house Polyester Powder Coating line to clients choice of RAL or BS standard colours.

Installation and Jointing

This rainwater pipe system is installed differently to a traditional rainwater pipe, as it is installed from the ground up. This allows the brackets to be encased by the pipe above, creating the "security" element, as there is no visible brackets or space between the wall and pipe to assist in climbing to higher roof levels. The waterproof seal between the two pipes is created with the use of a low modular sealant, such as Arbosil 1096. For step by step instructions please refer to ARP product installation guide.

Functional Life Expectancy

ARP qualifies that when installed correctly and maintained in accordance with its product guidelines and O&M procedure, its products are designed to give a minimum effective functional life expectancy of 30 years.

Specification Information

Clause: R10/311 Rainwater Drainage Systems
Product: Colonnade Square Security Pipe System
Manufacturer: ARP Ltd
 Unit 2 Vitruvius Way
 Meridian Business Park
 Braunstone, Leicester
 LE19 1WA

Handling & Storage

Gutters, downpipes and fittings, particularly with polyester powder coat finish should be handled with care and should preferably be stored under cover on racks to prevent scratching. All lengths are supplied in protective polythene wrapping, components suitably packed in boxes. If painted products are to be stored outside, cover with tarpaulin to guard against water ingress into the protective polythene. Mill finish items should be stored undercover to avoid uneven oxidation prior to being fitted.

Maintenance

In order to maintain proper working order, gutters should be periodically cleaned out and any built-up debris removed. Check all fixings are secure and take any remedial action to rectify if necessary. To maximise the life of the decorative paint finishes, all parts should be washed down with clean water at least every 12 months and any damage repaired. In marine/industrial environments, this period may need to be shortened to 6 months.

Further Information

Please visit www.arp-ltd.com or contact the ARP team of 0116 289 4400 for any other information